Submittal Sheet

Hamilton Prep Tex

Drywall Texture Base Coat

The production of a smooth, or lightly textured finish over gypsum drywall has always been a potential problem. Hamilton Prep Tex can be the solution.

MADE IN THE USA

What is it?

Prep Tex is a ready mixed drywall texture base coat designed to improve the quality of the drywall finish. It is recommended for use prior to the application of texture or decoration to minimize texture variation between finished gypsum surface and gypsum face paper. **It is not, and should not be considered as, a "sealer," or an architectural coating.**

Why do you need it?

There is, and has always been, a surface texture differential between the drywall face paper and joint compounds used for concealment of joints, fasteners and trims. Even with the best drywall finishing techniques, those surface differentials may be visible after texture and painting. The likelihood of this problem occurring is greatly increased when severe side lighting, gloss finishes or light textures are present. Prep Tex, when applied over a properly finished drywall installation, provides a surface with minimal differential, ready for decoration.

Benefits:

Prep Tex provides a smooth, sandable surface, eliminating problems often caused by porosity variations between finished joints and untreated gypsum wallboard paper.

P: (360) 225-6888 • P: (877) 443-7683 • Main Fax: (800) 871-5007 • CS Fax: (877) 5-FAX-HDP
295 North Pekin Road • Woodland, Washington 98674 • www.hamiltonnw.com

Prep Tex Product Data Sheet

1. Recommended Use

Any drywall surface to be decorated with gloss paints, or subject to severe lighting conditions, should be treated. Surfaces to be finished smooth, with no texture, whether flat or gloss finish is specified, should likewise be treated. This product is also recommended for use prior to application of texture to minimize texture pattern variation.

2. Packaging

18 Liter Plastic Pail /36 Pails per pallet

3. Coverage

Approximately 200 square feet per gallon when applied at 8-10 mil wet film thickness (full coat coverage is required to be effective)

4. Thinning

Prep Tex may be thinned by adding no more than 1/2 quart per gallon of clean water. **Do Not Overthin.**

5. Mixing

Mix by stirring. Power mixing at a high RPM is not recommended.

6. Job and Surface Conditions

Maintain a minimum air temperature of 50° F (10° C) during application, and until completely "dry" and stable. Surfaces must be thoroughly dry and free of dust and foreign substances. Glossy surfaces should be dulled and metal surfaces primed with a rust inhibitive primer. Particular attention should be given to metal trims with large exposed surfaces (such as "Bullnose") which ideally should be primed before application of Prep Tex.

7. Application

Recommended application of Prep Tex is by roller or airless spray. Either method produces minimal, if any, "stipple". Airless spray is the preferred method of application and produces excellent results.

8. Equipment

Roller Application: 3/8" to 1/2" nap roller.

Airless Spray: Minimum pump capacity of one gallon per minute. Recommended tip size .019" - .021". Various other tip sizes may be used depending on preference and skill of applicator.

9. Sanding

Prep Tex produces an excellent, sandable surface. In the event fine finish sanding is required, the use of 220 grit mesh screen is recommended. "Wet sanding" or sponging is preferred. **Do not over sand.**

10. Decoration

Prep Tex is designed as a basecoat for interior surfaces and is not intended as a sealer. Undercoaters and sealers may be applied directly over Prep Tex. Prep Tex does not address the problems associated with water soluble contaminants, nor lack of uniform holdout of gloss finishes, both of which should be covered by the painting specification.

Submittal Approvals

Job Name:

Contractor: **Date:**

P: (360) 225-6888 • P: (877) 443-7683 • Main Fax: (800) 871-5007 • CS Fax: (877) 5-FAX-HDP
295 North Pekin Road • Woodland, Washington 98674 • www.hamiltonnw.com